HP LaserJe All-in-One S

'Click' to download complete Manual







senice: iepairnanual.com

HP LaserJet 3390 all-in-one and LaserJet HP 3392 all-in-one

Service Manual



Copyright information

© 2005 Copyright Hewlett-Packard Development Company, L.P.

Reproduction, adaptation, or translation without prior written permission is prohibited, except as allowed under the copyright laws.

The information contained herein is subject to change without notice.

The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.

Part number Q6500-90901

Edition 1, 10/2005

Safety information

WARNING!

Potential Shock Hazard

Always follow basic safety precautions when using the all-in-one to reduce risk of injury from fire or electric shock.

Read and understand all instructions in the user guide.

Observe all warnings and instructions marked on the all-in-one.

Use only a grounded electrical outlet when connecting the all-in-one to a power source. If you do not know whether the outlet is grounded, check with a qualified electrician.

Do not touch the contacts on the end of any of the sockets on the all-in-one. Replace damaged cords immediately.

Unplug the all-in-one from wall outlets before cleaning.

Do not install or use the all-in-one near water or when you are wet.

Install the product securely on a stable surface.

Install the all-in-one in a protected location where no one can step on or trip over the power cord and where the power cord will not be damaged.

If the all-in-one does not operate normally, see the online user guide.

Refer all servicing questions to qualified personnel.

Information regarding FCC Class B, Parts 15 and 68 requirements can be found in the user guide.

Trademark credits

Microsoft® and Windows® are U.S. registered trademarks of Microsoft Corporation.

Linux is a U.S. registered trademark of Linus Torvalds.

UNIX® is a registered trademark of The Open Group.

Energy Star® and the Energy Star logo® are U.S. registered marks of the United States Environmental Protection Agency.



FCC Regulations

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy. If this equipment is not installed and used in accordance with the instructions, it may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase separation between equipment and receiver.

Connect equipment to an outlet on a circuit different from that to which the receiver is located.

Consult your dealer or an experienced radio/ TV technician.

Any changes or modifications to the printer that are not expressly approved by HP could void the user's authority to operate this equipment.

Use of a shielded interface cable is required to comply with the Class B limits of Part 15 of FCC rules.

This equipment complies with FCC rules, Parts 15 and 68. On the back of this equipment is a label that contains, among other information, the FCC registration number and ringer equivalence number (REN) for this equipment. If requested, this information must be provided to the telephone company. The REN is used to determine the quantity of devices which may be connected to the telephone line. Excessive RENs on the telephone line may result in the devices not ringing in response to an incoming call. In most, but not all, areas, the sum of the RENs should not exceed five (5.0). To be certain of the number of devices that may be connected to the line, as determined by the total RENs, contact the telephone company to determine the maximum REN for the calling area.

This equipment uses the following USOC jacks: RJ11C.

An FCC-compliant telephone cord and modular plug is provided with this equipment.

This equipment is designed to be connected to the telephone network or premises wiring using a compatible modular lack which is Part 68 compliant. This equipment cannot be used on telephone company-provided coin service. Connection to Party Line Service is subject to state tariffs. If this equipment causes harm to the telephone network, the telephone company will notify you in advance that temporary discontinuance of service may be required. If advance notice is not practical, the telephone company will notify the customer as soon as poss ble. Also, you will be advised of your right to file a complaint with the FCC if you believe it is necessary. The telephone company may make changes in its facilities, equipment, operations, or procedures that could affect the operation of the equipment. If this happens, the telephone company will provide advance notice in order for you to make the necessary modifications in order to maintain uninterrupted service. If trouble is experienced with this equipment, please see the numbers in the front of this manual for repair and (or) warranty information. If the trouble is causing harm to the telephone network, the telephone company may request you remove the equipment from the network until the problem is resolved. The following repairs can be done by the customer: Replace any original equipment that came with the device. This includes the print cartridge, the supports for trays and bins, the power cord, and the telephone cord. It is recommended that the customer install an ac surge arrestor in the ac outlet to which this device is connected. This is to avoid damage to the equipment caused by local lightning strikes and other electrical surges.

See the electronic user guide for more regulatory information.

Q6500-90901

service-repairmanual.com

Table of contents

1 All	-in-one information	
	Quick access to all-in-one information	2
	All-in-one configurations	3
	All-in-one features	
	Walkaround	
	HP LaserJet 3390/3392 all-in-one	
	Interface ports	9
	Control panel	9
	Model and serial numbers	10
	Software description	11
	Supported drivers	11
	Additional drivers	
	Software for Windows	12
	Windows software components	12
	HP ToolboxFX	
	Embedded Web server (EWS)	
	Software for Macintosh	13
	Macintosh software components	
	HP Director	
	Macintosh Configure Device (Mac OS X V10.3 and Mac OS X V10.4)	
	PDEs (Mac OS X V10.3 and Mac OS X V10.4)	
	Uninstalling software	
	Windows	
	Macintosh	
	Media specifications	
	Supported media weights and sizes	
	Media to avoid	
	Media that can damage the all-in-one	18
2 Ins	tallation	
	Operating environment	20
	Minimum system requirements	
	Unpacking	22
	Installing input devices	23
	ADF input tray	23
	250-sheet input tray (tray 3)	23
	Installing the control-panel faceplate	25
	Loading media	
	Loading documents onto the flatbed scanner or into the ADF	26

	Loading the single-sheet priority input slot (tray 1)	
	Loading tray 2 or optional tray 3	28
In	stalling accessories	30
	Removing and replacing a DIMM	30
3 Maintena	nce	
M	anaging supplies	34
	Life expectancies of supplies and the all-in-one	34
	Ordering supplies	34
	Storing supplies	34
	Replacing and recycling supplies	35
	Replacing the print cartridge	
	Replacing the staple cassette	40
	Replacing the tray 2 pickup roller	
	Replacing the tray 2 and optional tray 3 separation pad	
	Replacing the ADF pickup-roller assembly	
	HP policy on non-HP supplies	
	Resetting the all-in-one for non-HP supplies	
	HP fraud hotline	
C	leaning the all-in-one	
	Cleaning the flatbed scanner glass	
	Cleaning the scanner-cover backing	
	Cleaning the ADE pickup roller	
	Cleaning the ADF pickup-roller assembly Cleaning the print path	
M	anaging the all-in-one	
C:	Information pages	
i C	sing the HP ToolboxFX	
7,	To view the HP ToolboxFX	
	Status	
	Event log	
	Alerts	
	Set up status alerts	
	Set up e-mail alerts	
	Fax	
	Fax tasks	72
	Fax phone book	72
	Fax send log	75
	Fax receive log	75
	Help (Documentation)	75
	System settings	76
	Device information	76
	Paper handling	
	Print quality	
	Paper types	
	System setup	
	Service	
	Device Polling	
	Print settings	78

PCL 5e	79
PostScript	79
Network settings	79
Using Macintosh Configure Device (Mac OS X V10.3 and Mac OS X V10.4)	
Understanding the Embedded Web server	
Features	
4 Theory of operation	
Basic operation	84
Sequence of operation for the base unit	84
Internal components (base unit)	86
Engine control system	
Laser/scanner system	90
Pickup/feed/delivery system	
Image-formation system	
Scanner and ADF functions and operation	
Scanner functions	
Scanner operation	97
ADF operation	
ADF paper path and ADF sensors	
ADF jam detection	
Fax functions and operation	
PSTN operation	
To receive faxes when you hear fax tones	
Distinctive ring function	
The fax subsystem	
Formatter in the fax subsystem	
LIU in the fax subsystem	
Safety isolation	
Safety-protection circuitry	
Data path	
Hook state	
Downstream current detection	
Hook switch control	
Ring detect	
Line current control	
Billing (metering) tone filters	
Fax page storage in flash memory	
Stored fax pages	
Advantages of flash memory storage	
5 Removal and replacement	
Introduction	
Removal and replacement strategy	
Electrostatic discharge	
User-replaceable parts	
Required tools	
Before performing service	
After performing service	
Post-service tests	110

	Test 1 (print-quality test)	
	Test 2 (copy-quality test)	110
	Test 3 (fax-quality test)	111
	Parts-removal order	112
	Remove the print cartridge	113
	External panels, covers, and doors	114
	Right cover	114
	Left cover	116
	Print-cartridge door	118
	Rear cover	
	Top cover	
	ADF assembly	
	Scanner assembly	
	Bezel and control panel	
	Internal assemblies	
	Convenience-stapler assembly (HP LaserJet 3392 only)	
	Convenience-stapler power supply (HP LaserJet 3392 only)	
	Convenience-stapler ac inlet cable (HP LaserJet 3392 only)	
	Convenience-stapler power supply hacket and strap (HP LaserJet 3392 only)	
	Speaker	
	Power-switch PCA	
	Formatter	
	Duplex assembly	
	Laser/scanner	
	Memory-tag-reader assembly	
	Fuser	
	Fan	
	Euplex-drive gears	
	Duplex solenoid	
	Fuser	
	Interlock assembly	
	ECU	
	Main motor	
	Pickup-and-feed assemblies	
	Transfer roller	
	Registration-roller assembly	
	Main gear assembly and tray 2 pickup solenoid	
	Main gear assembly and tray 2 pickup soleholu	108
6 Tr	oubleshooting	
	Troubleshooting process	
	Troubleshooting checklist	
	Jams	177
	Causes of jams	
	Tips to avoid jams	
	Where to look for jams	178
	Jams in the print-cartridge area	
	Jams in the trays	18′
	Jams in the output bin	187
	Jams in the straight-through output path	
	Jams in the duplex path	190

viii ENWW

Jams in the ADF	195
Jams in the convenience stapler (HP LaserJet 3392 only)	200
Control-panel messages	203
Alert and warning messages	203
Alert and warning message tables	203
Critical-error message-tables	
Print problems	
Print-quality problems	
Improving print quality	211
Understanding print-quality settings	211
To temporarily change print-quality settings	
To change print-quality settings for all future jobs	
Identifying and correcting print defects	
Print-quality checklist	
General print-quality issues	
Media-handling problems	
Print-media guidelines	
Solving print-media problems	
Performance problems	
Fax problems	
Problems receiving faxes	
Problems sending faxes	
Voice-call problems	
Media-handling problems	
Performance problems	
Copy problems	
Preventing problems	
Image problems	
Media-handling problems	
Performance problems	
Scan problems	
Solving scanned-image problems	
Scan-quality problems	
Preventing problems	
Solving scan-quality problems	
Scan-specific error messages	
Control-panel display problems	
Convenience-stapler problems (HP LaserJet 3392 only)	
DSL problems	
PABX line problems	
ADF problems	
Functional checks	
Drum rotation test	
Engine test	
Half self-test functional check	
To perform a half self-test check	
To perform other checks	
Heating element check	
High-voltage contacts check	
To check the print-cartridge contacts	

	To check the high-voltage connector assembly	241
	Service-mode functions	242
	NVRAM initialization	242
	Secondary service menu	242
	Troubleshooting tools	244
	All-in-one pages and reports	244
	Demo page	244
	Configuration page	244
	Supplies Status page	244
	Fax reports	245
	Fax activity log	245
	Fax call report	245
	Phone book report	245
	Billing-code report	246
	HP ToolboxFX	246
	To view HP ToolboxFX	246
	Troubleshooting tab	246
	Service menu	247
	Restoring the factory-set defaults	247
	Cleaning the paper path	247
	T.30 protocol trace	248
	Archive print	248
	Firmware updates and recovery	249
	Firmware update by using a flash executable file	249
	Firmware-recovery DIMM	249
7 Parts		
	Accessories and ordering information	253
	Supplies	
	Memory	
	Cable and interface accessories	
	Paper-handling accessories	
	Scanner/ADF replacement parts	
	Control-panel bezels	
	Supplementary documentation and support	
	Troubleshooting diagrams	
	Repetitive image defects	
	Interface connectors	262
	Formatter connectors	263
	Line interface unit (LIU)	264
	Solenoids	264
	Switches and sensors	265
	Rollers and pads	266
	PCAs (base unit)	267
	Major components (base unit)	268
	Scanner and ADF	
	Circuit diagram	
	How to use the parts lists and diagrams	
	Types of screws	
	Scanner and ADF assemblies	

	Scanner components	274
	ADF components	276
	Convenience stapler components (HP LJ 3392 only)	278
	Formatter, LIU, HP jewel, and nameplate	280
	External covers and panels	282
	Internal components (1 of 4)	284
	Internal components (2 of 4)	286
	Internal components (3 of 4)	288
	Internal components (4 of 4)	290
	Engine-controller assembly	292
	Main-drive assembly	294
	Duplexing-drive assembly	296
	Tray 2 cassette and tray 3 cassette/feeder	298
	Duplexing assembly	300
	Fuser assembly	302
	Alphabetical parts list	304
	Numerical parts list	309
Annan	dix A All-in-cne specifications	
Appen	Physical specifications	316
	Supplies specifications	
	Performance	
	Eiectrical specifications	
	Power consumption	
	Environmental specifications	
5	Acoustic emissions	
	, 10040110 011110010110	
•	dia D. Managata information	
Appen	dix B Warranty information	200
	Hewlett-Packard limited warranty statement.	
	Print Cartridge Limited Warranty Statement	
	Extended warranty	328
Appen	dix C Regulatory statements	
	Declaration of conformity (HP LaserJet 3390, 3392, 3055, and 3050)	
	Country/region-specific safety statements	
	Laser safety statement	
	Canadian DOC statement	
	Korean EMI statement	
	Finnish laser statement	
	Japan power cord statement	332

ENWW